

Cat.6A/Class EA Modular RJ45 TIA568B - 6502846

<p>1</p> <p>For AWG 26 (OD 5mm-6mm)</p> <p>(option)</p> <p>Suited for AWG 22-26</p>	<p>2</p> <p>AWG 26 (if necessary)</p> <p>Step1 </p> <p>Step2 Stripping length min. 25mm </p> <p>Fold braid shield backwards</p> <p>Step3 </p> <p>Wrap braid shield evenly around cable jacket</p>	<p>3</p> <p>T568B</p> <table border="1"> <tr> <td>1 OR/WH</td> <td>2 OR</td> <td>7 BR/WH</td> <td>8 BR</td> </tr> <tr> <td>GN/WH</td> <td>6 GN</td> <td>BL/WH</td> <td>4 BL</td> </tr> <tr> <td>3</td> <td>6</td> <td>5</td> <td>4</td> </tr> </table> <p>T568B</p>	1 OR/WH	2 OR	7 BR/WH	8 BR	GN/WH	6 GN	BL/WH	4 BL	3	6	5	4	<p>4</p>	<p>5</p>
1 OR/WH	2 OR	7 BR/WH	8 BR													
GN/WH	6 GN	BL/WH	4 BL													
3	6	5	4													
<p>6</p> <p>click</p>	<p>7</p> <p>AWG 26 (if necessary)</p> <p>Remove the protective cover</p> <p>Slide cable forward until snap-in</p>	<p>8</p> <p>Press cap to Lock</p> <p>OD > 6mm OD 5mm-6mm</p>	<p>9</p> <p>Lock 1</p> <p>Bend cable along the concave slot 2</p> <p>45° by 8 slots for multi-direction entry</p> <p>3</p> <p>Cover with the cap and fasten</p> <p>4</p> <p>Lock</p> <p>Tighten cable gland until stop 5</p>	<p>10</p> <p>Complete termination</p>												

For retermination: Dismounting

<p>1</p> <p>Unlock</p>	<p>Face the latch downward</p> <p>Unlock</p>	<p>2</p> <p>Unlock</p>	<p>Unlock</p>	<p>3</p> <p>Unlock</p>
-------------------------------	--	-------------------------------	---------------	-------------------------------

