

UTP Industrial Field RJ45 Instruction TIA568B - 6502848

<p>1</p> <p>For AWG 26 (OD 5mm-6mm)</p> <p>(option)</p> <p>Suited for AWG 22-26</p>	<p>2</p> <p>Step1 AWG 26 (if necessary)</p> <p>Step2 min. 25mm Stripping length</p>	<p>3</p> <p>T568B</p> <p>1 OR/WH 2 OR 3 GN/WH 4 BL 5 BL/WH 6 GN 7 BR/WH 8 BR</p> <p>T568B</p>	<p>4</p>	<p>5</p>
<p>6</p> <p>click</p>	<p>7</p> <p>Remove the protective cover</p>	<p>8</p> <p>Lock</p> <p>Slide cable forward until snap-in</p>	<p>9</p> <p>Lock</p> <p>1. Press SR to Lock 2. Tighten cable gland until stop</p>	<p>10</p> <p>Complete termination</p>

For retermination: Dismounting

<p>1</p> <p>Unlock</p>	<p>Face the latch downward</p> <p>Unlock</p>	<p>2</p> <p>Unlock</p>	<p>Unlock</p>	<p>3</p> <p>Unlock</p>
-------------------------------	--	-------------------------------	---------------	-------------------------------

